

Orchestra Shell Risers and Staging Dimensions

ORCHESTRA SHELL DIMENSIONS

Large Shell: (Atwood Only)

Walls #1, #10	30' High
Walls #2, #9	28' High
Walls #3, #8	26' High - Single Door
Walls #4, #5, #6, #7	22' High
Door	3' 8" Wide
Facing	6' 9" Width between doors

Full Shell Set-up: (Atwood Only)

Downstage	55' Wide x 30' High
Upstage	42' 7" Wide x 22' High
Stage edge to back wall	38' 10"

Half Shell Set-up: (Atwood Only)

Downstage	55' Wide x 30' High
Upstage	51' 4" Wide x 22' High
Stage edge to back wall	19' 9"

Small Shell:

06	Walls	6' Wide x 13' 11" to 15' 2" High
12	Walls	6' Wide x 9' 3" High
18	Lever Ceiling	6' Wide to 5' Wide x 4' High (Discovery Only)
12	Ceiling Clouds	4' Wide x 8 Long

Orchestra /Chorus Risers (Rental)**Rectangle:****(#) H x W x L**

(5) 32" x 3' x 8'

(6) 24" x 3' x 8'

(5) 16" x 3' x 8'

(5) 8" x 3' x 8'

(2) 16" x 4' x 8'

(1) 24" x 3' x 6'

(1) 16" x 3' x 6'

(1) 8" x 3' x 6'

Parallelogram:**(#) H x W x DSL x USL**

(8) 32" x 3 x 4' x 5' 1"

(4) 24" x 2'10" x 5'8" x 8'

(4) 16" x 2'10" x 3'5" x 5'8"

(4) 8" x 2'10" x 1'1" x 3'5"

Staging: (Rental)

(6) 24"/36" x 6' x 8'

(6) 16"/24" x 6' x 8'

(1) Stairs 16" High, 2 step

Symphony Chairs : 110 Black

Music Stands (Rental): 90 (stand lights available)